

TECHNICAL MANUAL

OPERATION AND MAINTENANCE INSTRUCTIONS

STORAGE TANK, LIQUID OXYGEN

TYPE TMU-7A/E

2,000 GALLON CAPACITY

PART NO. C70013

NSN 3655-01-245-8408YD

HYDRA-RIG CRYOGENICS, INC.
F41608-86-D-0268
F09603-99-D-0382

DISTRIBUTION STATEMENT - Distribution authorized to U.S. Government Agencies only (Administrative or Operational Use) (1 September 1988). Other requests for this document shall be referred to WR-ALC/LKC, Robins AFB, GA 31098. Questions concerning technical content shall be referred to WR-ALC/LES.

WARNING - This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et seq.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App. 2401 et seq. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

HANDLING AND DESTRUCTION NOTICE - Comply with distribution statement and destroy by any method that will prevent disclosure of contents or reconstruction of the document.

Published Under Authority of the Secretary of the Air Force

LIST OF EFFECTIVE PAGES

INSERT LATEST CHANGED PAGES. DESTROY SUPERSEDED PAGES.

NOTE: The portion of the text affected by the changes is indicated by a vertical line in the margins of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by miniature pointing hands or by shaded areas. A vertical line running the length of a figure in the outer margin of the page indicates that the figure is being added.

Dates of issue for original and changed pages are:

Original 0 1 September 1988
Change. 1 15 August 2003

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 46, CONSISTING OF THE FOLLOWING:

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
Title	1				
A.	1				
i - iv	1				
a - c.	0				
1-0	0				
1-1 - 1-3	0				
1-4	1				
2-1	0				
2-2 Blank	0				
3-1 - 3-4	0				
4-1 - 4-8	0				
5-1 - 5-12	0				
6-1	0				
6-2 Blank	0				
7-1	0				
7-2 Blank	0				
8-1	0				
8-2 Blank	0				

*Zero in this column indicates an original page.

FOREWORD

Purpose. This technical manual will provide the using activity with operation and service instructions for the Liquid Oxygen Storage and Transfer Tank, Type TMU-7A/E.

Scope. This manual will provide the using activity with applicable information required on the handling, storage, and hazards associated with the use of cryogenic equipment and products. Any corrections regarding this technical manual should be submitted in accordance with TO 00-5-1.

Throughout this manual the unit will primarily be called the Tank. It may also be called the Storage Tank. Tanks referenced but not covered by this manual will contain additional descriptions. Example: supply tank and receiving tank. Liquid oxygen may be referred to as the product, or abbreviated as LOX in parts of this manual.

TABLE OF CONTENTS

Chapter	Page	Chapter	Page
FOREWORD.....	i	3-7 Preparation for Storage and Shipment.....	3-2
LIST OF ILLUSTRATIONS.....	iv	3-7.2 General Preparations.....	3-3
LIST OF TABLES.....	iv	3-7.3 Tank Shipment.....	3-3
SAFETY SUMMARY	a	3-7.4 Tank Storage	3-4
I INTRODUCTION AND GENERAL INFORMATION	1-1	IV OPERATING INSTRUCTIONS.....	4-1
1-1 Introduction.....	1-1	4-1 Theory of Operation.....	4-1
1-1.1 Purpose.....	1-1	4-2 Operating Controls.....	4-1
1-1.2 Scope.....	1-1	4-2.1 Purpose and Use of Operating Controls.....	4-1
1-1.3 Arrangement.....	1-1	4-3 Additional Tank Equipment.....	4-3
1-2 General Information	1-1	4-3.1 Purpose and Use of Additional Tank Equipment	4-3
1-2.1 Purpose of Equipment.....	1-1	4-4 Operating Instructions.....	4-4
1-2.2 Physical Description	1-1	4-4.1 Basic Instructions.....	4-4
1-2.3 Leading Particulars	1-3	4-5 Filling the Tank	4-4
1-2.4 Related Publications.....	1-3	4-5.1 Types of Filling.....	4-4
1-2.5 Safety Precautions.....	1-3	4-5.2 Filling an Ambient/Purged Tank.....	4-4
1-2.6 Properties of Liquid Oxygen.....	1-3	4-5.3 Filling a Chilled Tank	4-6
1-2.7 Tank Management.....	1-3	4-6 Servicing with the Tank	4-6
1-3 Consumable Materials List	1-4	4-6.1 Servicing Tanks with Product.....	4-6
II SPECIAL TOOLS AND EQUIPMENT.....	2-1	4-7 Draining the Tank	4-7
2-1 General	2-1	4-7.1 Draining Product from the Tank	4-7
III PREPARATION FOR USE, STORAGE AND SHIPMENT	3-1	4-8 Product Sampling.....	4-8
3-1 General	3-1	4-8.1 Obtaining Product Samples.....	4-8
3-1.1 Scope.....	3-1	V MAINTENANCE INSTRUCTIONS	5-1
3-2 Preparation for Use	3-1	5-1 Inspection and Preventative Maintenance.....	5-1
3-2.1 Preparing the Tank	3-1	5-1.1 Scope.....	5-1
3-2.2 Tank Condition Upon Receipt	3-1	5-1.2 Periodic Inspection.....	5-1
3-3 External Surfaces	3-1	5-1.3 Periodic Lubrication.....	5-1
3-3.1 Preparation	3-1	5-1.4 Troubleshooting	5-1
3-4 Location	3-2	5-1.5 General Maintenance Instructions	5-1
3-4.1 Selection of an Operating Site	3-2	5-2 Fill/Drain Line Components	5-1
3-4.2 Type Site	3-2	5-2.1 Fill/Drain Line (FDL) Filter (F-2)	5-1
3-5 Lifting and Moving the Tank	3-2	5-2.2 Fill/Drain Line (FDL) Drain Valve (V-6).....	5-2
3-5.1 Lifting and Moving Methods	3-2	5-2.3 Fill/Drain Line (FDL) Pressure Relief Valve (RV-2).....	5-2
3-6 Static Grounding	3-2	5-2.4 Fill/Drain Line (FDL) LOX Coupling	5-2
3-6.1 Grounding Requirements	3-2	5-3 Servicing Line Components.....	5-4
		5-3.1 Servicing Line (SL) Filter (F-1).....	5-4
		5-3.2 Servicing Line (SL) Drain Valve (V-4).....	5-4

TABLE OF CONTENTS - Continued

Chapter	Page	Chapter	Page
5-3.3 Servicing Line (SL) Pressure Relief Valve (RV-1)	5-6	VI DIAGRAMS	6-1
5-3.4 Servicing Line (SL) LOX Coupling.....	5-6	6-1 Flow Schematic Diagram	6-1
5-4 Control Panel Components	5-6	6-1.2 Scope	6-1
5-4.1 Liquid Level Indicator (LL-1).....	5-6	VII ILLUSTRATED PARTS BREAKDOWN	7-1
5-4.2 Level Indicator Equalizer Valve (V-12).....	5-6	7-1 Illustrated Parts Breakdown	7-1
5-5 Vacuum System Maintenance.....	5-8	7-1.1 Scope	7-1
5-5.1 Tank Efficiency	5-8	VIII DIFFERENCE DATA SHEETS.....	8-1
5-5.2 Evidence of Vacuum Loss.....	5-8	8-1 Difference Data Sheets.....	8-1
5-5.3 Repair Procedures	5-9	8-1.1 Scope	8-1
5-5.4 Vacuum Efficiency Test Procedures	5-9		

LIST OF ILLUSTRATIONS

Number	Title	Page	Number	Title	Page
1-1	Tank, Storage, Liquid Oxygen, Type TMU-7A/E.....	1-0	5-1	Fill/Drain Line Component Removal and Replacement	5-3
2-1	Gage, Vacuum	2-1	5-2	Service Line Component Removal and Replacement	5-5
2-2	Meter, Dual Efficiency.....	2-1	5-3	Control Panel Component Removal and Replacement	5-7
3-1	Lifting Instructions	3-3	5-4	Annular Space Efficiency Test	5-8
3-2	Approved Method for Static Grounding	3-4	6-1	Tank Flow Schematic Diagram	6-1
4-1	Component Identification	4-2			

LIST OF TABLES

Number	Title	Page	Number	Title	Page
1-1	Leading Particulars	1-2	4-1	Valve Positions During Tank Operations	4-5
1-2	Related Publications	1-3	5-1	Troubleshooting Procedures	5-10
1-3	Consumable Materials List	1-4			
2-1	Special Tools and Equipment	2-1			

1-2.3 Leading Particulars. A summary of leading particulars for the Tank appears in Table 1-1.

1-2.4 Related Publications. The publications listed in Table 1-2 are required and shall be used with this publication, the Repair and Overhaul Instructions, T.O.37C2-8-24-3, and the Illustrated Parts Breakdown, T.O.37C2-8-24-4 in the operation, maintenance, service, and repair of the Tank.

1-2.5 Safety Precautions. Safety precautions related to liquid oxygen and this Tank are listed in the Safety Summary. Safety precautions which are related to specific procedures will appear in the text.

1-2.6 Properties of Liquid Oxygen (LOX).

LOX is a pale blue, nonviscous, water-like fluid. At atmospheric pressure it is 1.14 times heavier than water and weighs 9.527 pounds per gallon. LOX boils at -297° F. When LOX is converted to a gaseous state it expands to about 860 times its original volume. One cubic foot of LOX (7.5 gallons) will expand to about 860 cubic feet of gaseous oxygen at 70° F. For additional information about LOX refer to T.O.42B6-1-1.

1-2.7 Tank Management. This Tank is classified as FSC 3655 registered Air Force Ground Support Equipment. It is to be managed under provisions of AFR 66-1. Using activities will record the USAF registration number located on the

Table 1-2. Related Publications.

Publication No.	Title
T.O.00-5-1	AF Technical Order System
T.O.00-25-107	AFLC Area Support
T.O.00-25-172	Ground Servicing of Aircraft and Static Grounding/Bonding
T.O.00-25-223	Integrated Pressure Systems and Components
T.O.00-25-224	Welding High Pressure and Cryogenic Systems
T.O.00-25-229	Valves and Regulators
T.O.33D2-10-60-1	Cryogenic Sampler
T.O.34Y5-3-37-1	Operation and Maintenance Instructions Power Driven Rotary Vacuum Pump
T.O.00-35D-54	USAF Material Deficiency Reporting and Investigating System
T.O.35-1-3	Painting and Marking of USAF Aerospace Ground Equipment
T.O.37C2-8-29-3	Liquid Oxygen Storage Tank, Overhaul and Repair Instructions
T.O.37C2-8-29-4	Liquid Oxygen Storage Tank, Illustrated Parts Breakdown
T.O.37C2-8-1-116WC-1	Inspection Work Cards
T.O.37C2-8-27-11	Operation, Maintenance and Overhaul Instructions with Illustrated Parts Breakdown Meter, Dual Efficiency
T.O.37C11-3-1	Vacuum Gage (Portable), Part No. 15840
T.O.36G2-3-1	Air Purging Unit, Type GSU-62/M
T.O.37C11-1-1	Cleaning of Pressure Gages Used
T.O.42B6-1-1	Quality Control of Oxygen
AFOSH-STD-127-66	Occupational Safety General Industrial Operations
AFR-144-1	Fuels Management
MIL-STD-1359A	Cleaning Methods and Procedures for Breathing Oxygen Equipment

Tank's data plate. The USAF registration number consists of a 13 digit, alphanumerical arrangement which indicates: (1) The Federal Supply Class, (2) Calendar year in which the Tank was built, (3) Federal Item Identification Number (FIIN) and (4) Assigned Serial Number. When the serial number consists of fewer than four digits, zeros will be added in front of the serial number. Example: Hydra Rig Cryogenics manufactured Tanks, Type TMU-7A/E, NSN 3655-01-087-0001YD and delivered them in the year 1987 with serial numbers beginning with 001.

The Federal Identification Number assigned these Tanks is EAB for LOX tanks. The sample USAF registration number, therefore, would be 3655-01-EAB-0001. Compliance with the afore stated instructions shall be reported in accordance with AFR 66-1 and TO 00-25-215.

1-3 CONSUMMABLE MATERIALS LIST.

1-3.1 Materials used in the maintenance of the Tank at the operating level are listed in Table 1-3.

Table 1-3. Consumable Materials List.

Material	Spccification	Federal Stock No.
Tape, Antiseize (1/2-inch)	MIL-T-27730A	8030-00-889-3535
Nitrogen	BB-N-411	6830-00-285-4769
Leak Detection Compound, Oxygen Systems, Type 1	MIL-L-25567C	6850-00-621-1820
Solvent, trichlorotrifluoroethane	MIL-C-81302	